

# HONDA

Replica Plastics

## REAR SHOCK FLAPS

New models of rear shock flaps are now available. An extended range, produced with a flexible plastic material to give the part the best performance. All available in black and brand colors.



**NEW**



**DGP**  
durable glass polypropylene

CRF450F\_2017

## MX KIT

MODEL	YEAR	COLOR	PVP	KIT REF.
<b>CRF50F</b>	04-17	OEM Color <span style="color:red">0</span> <sub>04-13</sub>	58,00	90025
<b>CR85R</b>	03-07	OEM Color <span style="color:red">0</span>	78,00	90078
<b>CRF110F</b>	13-17	OEM Color <span style="color:red">0</span>	78,00	90537
		white	78,00	90538
		black	78,00	90539
<b>CR125R</b>	95-97	OEM Color <span style="color:red">0</span> <sub>95-96</sub>	78,00	90079
	98-99	OEM Color <span style="color:red">0</span>	78,00	90080
	00-01	OEM Color <span style="color:red">0</span>	78,00	90081
	02-03	OEM Color <span style="color:red">0</span>	78,00	90604
	04-07	OEM Color <span style="color:red">0</span>	78,00	90082
<b>CR250R</b>	95-96	OEM Color <span style="color:red">0</span>	78,00	90079
	97-99	OEM Color <span style="color:red">0</span>	78,00	90080
	00-01	OEM Color <span style="color:red">0</span>	78,00	90081
	02-03	OEM Color <span style="color:red">0</span>	78,00	90604
	04-07	OEM Color <span style="color:red">0</span>	78,00	90082
<b>CRF150R</b>	07-17	OEM Color <span style="color:red">0</span>	78,00	90135
		white	78,00	90159
<b>CRF250R</b>	04-05	OEM Color <span style="color:red">0</span>	78,00	90083
	06-07	OEM Color <span style="color:red">0</span>	78,00	90115
		white	78,00	90139
	08	OEM Color <span style="color:red">0</span>	78,00	90142
		white	78,00	90143
	08	black	78,00	90144
		09	OEM Color <span style="color:red">0</span>	78,00
	10	OEM Color <span style="color:red">0</span>	89,00	90154
		white	89,00	90211
	10	black	89,00	90212
11-13		OEM Color <span style="color:red">0</span>	89,00	90423
	white	89,00	90421	
14-17	OEM Color <span style="color:red">0</span>	89,00	90536	
	white	89,00	90561	
	black	89,00	90562	
14-17	red cr04	89,00	90628	

## KIT CONTENTS

front fender	rear fender	radiator scoops	airbox covers	side panels	number plate
<span style="color:red">R-CR4</span> 8563100003	<span style="color:red">R-CR4</span> 8563200003	<span style="color:red">R-CR4</span> 8429900003	-	<span style="color:red">WH</span> 8602000001	<span style="color:red">WH</span> 8661800001
<span style="color:red">R-CR4</span> 8563300001	<span style="color:red">R-CR4</span> 8563400001	<span style="color:red">R-CR4</span> 8410600001	-	<span style="color:red">WH</span> 8602100001	<span style="color:red">WH</span> 8662200001
<span style="color:red">R-CR4</span> 8573500001	<span style="color:red">WH</span> 8579300002	<span style="color:red">R-CR4</span> 8416200001	<span style="color:red">UR</span> -	<span style="color:red">WH</span> 8606600002	<span style="color:red">LR</span> <span style="color:red">WH</span> 8658800002
<span style="color:red">WH</span> 8573500002	<span style="color:red">WH</span> 8579300002	<span style="color:red">WH</span> 8416200002	<span style="color:red">UR</span> -	<span style="color:red">WH</span> 8606600002	<span style="color:red">LR</span> <span style="color:red">WH</span> 8658800002
<span style="color:red">BK</span> 8573500003	<span style="color:red">BK</span> 8579300003	<span style="color:red">BK</span> 8416200003	<span style="color:red">UR</span> -	<span style="color:red">BK</span> 8606600003	<span style="color:red">LR</span> <span style="color:red">BK</span> 8658800003
<span style="color:red">FLUO-R</span> 8591000010	<span style="color:red">FLUO-R</span> 8588000003	<span style="color:red">BK</span> 8410000002	-	<span style="color:red">WH</span> 8411000001	<span style="color:red">WH</span> 8673000002
<span style="color:red">FLUO-R</span> 8591000010	<span style="color:red">FLUO-R</span> 8593000003	<span style="color:red">FLUO-R</span> 8417000003	-	<span style="color:red">WH</span> 8416000001	<span style="color:red">WH</span> 8673000002
<span style="color:red">R-CR0</span> 8550000013	<span style="color:red">R-CR0</span> 8551000003	<span style="color:red">R-CR0</span> 8421000003	-	<span style="color:red">WH</span> 8601000001	<span style="color:red">WH</span> 8657000001
<span style="color:red">R-CR4</span> 8550000017	<span style="color:red">R-CR4</span> 8560600009	<span style="color:red">R-CR4</span> 8427000007	-	<span style="color:red">WH</span> 8600700001	<span style="color:red">WH</span> 8657000001
<span style="color:red">R-CR4</span> 8562600003	<span style="color:red">R-CR4</span> 8560600009	<span style="color:red">R-CR4</span> 8427000007	-	<span style="color:red">WH</span> 8600700001	<span style="color:red">WH</span> 8661900001
<span style="color:red">BK</span> 8562600002	<span style="color:red">BK</span> 8560600002	<span style="color:red">BK</span> 8427000002	-	<span style="color:red">BK</span> 8600700002	<span style="color:red">BK</span> 8661900002
<span style="color:red">FLUO-R</span> 8591000010	<span style="color:red">FLUO-R</span> 8588000003	<span style="color:red">BK</span> 8410000002	-	<span style="color:red">WH</span> 8411000001	<span style="color:red">WH</span> 8673000002
<span style="color:red">FLUO-R</span> 8591000010	<span style="color:red">FLUO-R</span> 8593000003	<span style="color:red">FLUO-R</span> 8417000003	-	<span style="color:red">WH</span> 8416000001	<span style="color:red">WH</span> 8673000002
<span style="color:red">R-CR0</span> 8550000013	<span style="color:red">R-CR0</span> 8551000003	<span style="color:red">R-CR0</span> 8421000003	-	<span style="color:red">WH</span> 8601000001	<span style="color:red">WH</span> 8657000001
<span style="color:red">R-CR4</span> 8550000017	<span style="color:red">R-CR4</span> 8560600009	<span style="color:red">R-CR4</span> 8427000007	-	<span style="color:red">WH</span> 8600700001	<span style="color:red">WH</span> 8657000001
<span style="color:red">R-CR4</span> 8562600003	<span style="color:red">R-CR4</span> 8560600009	<span style="color:red">R-CR4</span> 8427000007	-	<span style="color:red">WH</span> 8600700001	<span style="color:red">WH</span> 8661900001
<span style="color:red">BK</span> 8562600002	<span style="color:red">BK</span> 8560600002	<span style="color:red">BK</span> 8427000002	-	<span style="color:red">BK</span> 8600700002	<span style="color:red">BK</span> 8661900002
<span style="color:red">R-CR4</span> 8569200001	<span style="color:red">R-CR4</span> 8569100001	<span style="color:red">R-CR4</span> 8412200001	-	<span style="color:red">WH</span> 8604000001	<span style="color:red">WH</span> 8663200001
<span style="color:red">WH</span> 8569200002	<span style="color:red">WH</span> 8569100002	<span style="color:red">WH</span> 8412200002	-	<span style="color:red">WH</span> 8604000001	<span style="color:red">WH</span> 8663200001
<span style="color:red">R-CR4</span> 8562600003	<span style="color:red">R-CR4</span> 8562700003	<span style="color:red">R-CR4</span> 8410300003	-	<span style="color:red">R-CR4</span> <span style="color:red">WH</span> 8601800001	<span style="color:red">WH</span> 8661900001
<span style="color:red">R-CR4</span> 8562600003	<span style="color:red">R-CR4</span> 8551100003	<span style="color:red">R-CR4</span> 8410300003	-	<span style="color:red">R-CR4</span> <span style="color:red">WH</span> 8602800001	<span style="color:red">WH</span> 8661900001
<span style="color:red">WH</span> 8562600001	<span style="color:red">WH</span> 8551100001	<span style="color:red">WH</span> 8410300001	-	<span style="color:red">WH</span> 8602800008	<span style="color:red">WH</span> 8661900001
<span style="color:red">R-CR4</span> 8562600003	<span style="color:red">R-CR4</span> 8550100003	<span style="color:red">R-CR4</span> 8410300003	-	<span style="color:red">R-CR4</span> <span style="color:red">WH</span> 8602800001	<span style="color:red">WH</span> 8657500001
<span style="color:red">WH</span> 8562600001	<span style="color:red">WH</span> 8550100001	<span style="color:red">WH</span> 8410300001	-	<span style="color:red">WH</span> 8602800008	<span style="color:red">WH</span> 8657500001
<span style="color:red">BK</span> 8562600002	<span style="color:red">BK</span> 8550100002	<span style="color:red">BK</span> 8410300002	-	<span style="color:red">BK</span> 8602800002	<span style="color:red">BK</span> 8657500002
<span style="color:red">R-CR4</span> 8562600003	<span style="color:red">WH</span> 8550100001	<span style="color:red">R-CR4</span> 8410300003	-	<span style="color:red">WH</span> 8602800008	<span style="color:red">WH</span> 8657500001
<span style="color:red">R-CR4</span> 8572700001	<span style="color:red">WH</span> 8578700002	<span style="color:red">R-CR4</span> 8412700001	<span style="color:red">R-CR4</span> 8604500001	<span style="color:red">WH</span> 8604700002	<span style="color:red">WH</span> 8656700001
<span style="color:red">WH</span> 8572700002	<span style="color:red">WH</span> 8578700002	<span style="color:red">WH</span> 8412700002	<span style="color:red">WH</span> 8604500002	<span style="color:red">WH</span> 8604700002	<span style="color:red">WH</span> 8656700001
<span style="color:red">BK</span> 8572700003	<span style="color:red">BK</span> 8578700003	<span style="color:red">BK</span> 8412700003	<span style="color:red">BK</span> 8604500003	<span style="color:red">BK</span> 8604700003	<span style="color:red">BK</span> 8656700002
<span style="color:red">R-CR4</span> 8572700001	<span style="color:red">WH</span> 8578700002	<span style="color:red">R-CR4</span> 8412700001	<span style="color:red">R-CR4</span> 8604500001	<span style="color:red">WH</span> 8605500001	<span style="color:red">WH</span> 8656700001
<span style="color:red">WH</span> 8572700002	<span style="color:red">WH</span> 8578700002	<span style="color:red">WH</span> 8412700002	<span style="color:red">WH</span> 8604500002	<span style="color:red">WH</span> 8605500001	<span style="color:red">WH</span> 8656700001
<span style="color:red">R-CR4</span> 8573900001	<span style="color:red">WH</span> 8579500002	<span style="color:red">R-CR4</span> <span style="color:red">WH</span> 8417100001	<span style="color:red">WH</span> 8605300002	<span style="color:red">WH</span> 8606800002	<span style="color:red">WH</span> 8659400002
<span style="color:red">WH</span> 8573900002	<span style="color:red">WH</span> 8579500002	<span style="color:red">WH</span> 8417100002	<span style="color:red">WH</span> 8605300002	<span style="color:red">WH</span> 8606800002	<span style="color:red">WH</span> 8659400002
<span style="color:red">BK</span> 8573900003	<span style="color:red">BK</span> 8579500003	<span style="color:red">BK</span> 8417100003	<span style="color:red">BK</span> 8605300003	<span style="color:red">BK</span> 8606800003	<span style="color:red">BK</span> 8659400003
<span style="color:red">R-CR4</span> 8573900001	<span style="color:red">R-CR4</span> 8579500001	<span style="color:red">R-CR4</span> 8417100004	<span style="color:red">R-CR4</span> 8605300001	<span style="color:red">R-CR4</span> 8606800001	<span style="color:red">R-CR4</span> 8659400001

BK black WH white red cr04 R-CR0 red cr00 FLUO-R fluo red

UR only upper radiator scoops LR lower radiator scoops + side panels HEAT PROTECTION

OEM colors - Original equipment manufacturer color 0 OEM color 09 OEM color for 09

04-13 OEM color since 04 until 13

NEW New replica part for 2017

NEWCOLOR New replica part color for 2017

# HONDA

Replica Plastics

## MX KIT

MODEL	YEAR	COLOR	PVP	KIT REF.
CRF450R	02-03	OEM Color	78,00	90085
	04	OEM Color	78,00	90109
	05-06	OEM Color	78,00	90084
	07	OEM Color	78,00	90125
	08	OEM Color	78,00	90175
	09-10	OEM Color	89,00	90154
		white	89,00	90211
		black	89,00	90212
	11-12	OEM Color	89,00	90423
		white	89,00	90421
13-16	OEM Color	89,00	90536	
	white	89,00	90561	
	black	89,00	90562	
	red cr04	89,00	90628	
17	<b>NEW</b> OEM Color	89,00	90719	
	<b>NEW</b> white	89,00	90720	
	<b>NEW</b> black	89,00	90721	
	<b>NEW</b> red cr04	89,00	90722	
<b>USA NEW</b>	OEM Color	89,00	90733 <sup>(1)</sup>	

(1) This kit includes airbox covers with air intake.

## ENDUROKIT

MODEL	YEAR	COLOR	PVP	KIT REF.
CRF450RX	17	<b>NEW</b> OEM Color	89,00	90719
		<b>NEW</b> white	89,00	90720
		<b>NEW</b> black	89,00	90721
		<b>NEW</b> red cr04	89,00	90722
<b>USA NEW</b>	OEM Color	89,00	90733 <sup>(1)</sup>	

(1) This kit includes airbox covers with air intake.

## KIT CONTENTS

front fender	rear fender	radiator scoops	airbox covers	side panels	number plate
<b>R-CR4</b> 8550000017	<b>R-CR4</b> 8560900010	<b>R-CR4</b> 8429000011	-	<b>WH</b> 8600900001	<b>WH</b> 8657000001
<b>R-CR4</b> 8562600003	<b>R-CR4</b> 8560900010	<b>R-CR4</b> 8429000011	-	<b>WH</b> 8600900001	<b>WH</b> 8661900001
<b>R-CR4</b> 8562600003	<b>R-CR4</b> 8565300003	<b>R-CR4</b> 8411300003	-	<b>WH</b> 8602600001	<b>WH</b> 8661900001
<b>R-CR4</b> 8562600003	<b>R-CR4</b> 8565300003	<b>R-CR4</b> 8411300003	-	<b>R-CR4 WH</b> 8603900001	<b>WH</b> 8661900001
<b>R-CR4</b> 8562600003	<b>R-CR4</b> 8565300003	<b>R-CR4</b> 8411300003	-	<b>R-CR4 WH</b> 8603900001	<b>WH</b> 8657500001
<b>R-CR4</b> 8572700001	<b>WH</b> 8578700002	<b>R-CR4</b> 8412700001	<b>R-CR4</b> 8604500001	<b>WH</b> 8604700002	<b>WH</b> 8656700001
<b>WH</b> 8572700002	<b>WH</b> 8578700002	<b>WH</b> 8412700002	<b>WH</b> 8604500002	<b>WH</b> 8604700002	<b>WH</b> 8656700001
<b>BK</b> 8572700003	<b>BK</b> 8578700003	<b>BK</b> 8412700003	<b>BK</b> 8604500003	<b>BK</b> 8604700003	<b>BK</b> 8656700002
<b>R-CR4</b> 8572700001	<b>WH</b> 8578700002	<b>R-CR4</b> 8412700001	<b>R-CR4</b> 8604500001	<b>WH</b> 8605500001	<b>WH</b> 8656700001
<b>WH</b> 8572700002	<b>WH</b> 8578700002	<b>WH</b> 8412700002	<b>WH</b> 8604500002	<b>WH</b> 8605500001	<b>WH</b> 8656700001
<b>R-CR4</b> 8573900001	<b>WH</b> 8579500002	<b>R-CR4 WH</b> 8417100001	<b>WH</b> 8605300002	<b>WH</b> 8606800002	<b>WH</b> 8659400002
<b>WH</b> 8573900002	<b>WH</b> 8579500002	<b>WH</b> 8417100002	<b>WH</b> 8605300002	<b>WH</b> 8606800002	<b>WH</b> 8659400002
<b>BK</b> 8573900003	<b>BK</b> 8579500003	<b>BK</b> 8417100003	<b>BK</b> 8605300003	<b>BK</b> 8606800003	<b>BK</b> 8659400003
<b>R-CR4</b> 8573900001	<b>R-CR4</b> 8579500001	<b>R-CR4</b> 8417100004	<b>R-CR4</b> 8605300001	<b>R-CR4</b> 8606800001	<b>R-CR4</b> 8659400001
<b>R-CR4</b> 8553200001	<b>R-CR4</b> 8554100001	<b>R-CR4 BK</b> 8414800001	<b>R-CR4</b> 8418700001	<b>WH</b> 8418600002	<b>WH</b> 8667200002
<b>WH</b> 8553200002	<b>WH</b> 8554100002	<b>WH</b> 8414800002	<b>WH</b> 8418700002	<b>WH</b> 8418600002	<b>WH</b> 8667200002
<b>BK</b> 8553200003	<b>BK</b> 8554100003	<b>BK</b> 8414800003	<b>BK</b> 8418700003	<b>BK</b> 8418600003	<b>BK</b> 8667200003
<b>R-CR4</b> 8553200001	<b>R-CR4</b> 8554100001	<b>R-CR4</b> 8414800004	<b>R-CR4</b> 8418700001	<b>R-CR4</b> 8418600001	<b>R-CR4</b> 8667200001
<b>R-CR4</b> 8553200001	<b>R-CR4</b> 8554100001	<b>R-CR4 BK</b> 8414800001	<b>R-CR4</b> 8415100001	<b>WH</b> 8418600002	<b>WH</b> 8667200002

## KIT CONTENTS

front fender	rear fender	radiator scoops	airbox covers	side panels	number plate
<b>R-CR4</b> 8553200001	<b>R-CR4</b> 8554100001	<b>R-CR4 BK</b> 8414800001	<b>R-CR4</b> 8418700001	<b>WH</b> 8418600002	<b>WH</b> 8667200002
<b>WH</b> 8553200002	<b>WH</b> 8554100002	<b>WH</b> 8414800002	<b>WH</b> 8418700002	<b>WH</b> 8418600002	<b>WH</b> 8667200002
<b>BK</b> 8553200003	<b>BK</b> 8554100003	<b>BK</b> 8414800003	<b>BK</b> 8418700003	<b>BK</b> 8418600003	<b>BK</b> 8667200003
<b>R-CR4</b> 8553200001	<b>R-CR4</b> 8554100001	<b>R-CR4</b> 8414800004	<b>R-CR4</b> 8418700001	<b>R-CR4</b> 8418600001	<b>R-CR4</b> 8667200001
<b>R-CR4</b> 8553200001	<b>R-CR4</b> 8554100001	<b>R-CR4 BK</b> 8414800001	<b>R-CR4</b> 8415100001	<b>WH</b> 8418600002	<b>WH</b> 8667200002